

1991 Swan-Matic Single Cycle CapMaster C300

Mfg: Swan-Matic

Model: CapMaster C300

Stock No. SUBF223.3a

Serial No. 3656

1991 Swan-Matic Single Cycle CapMaster C300. Model: CapMaster C300. S/N: 3656. Capacity: Approximately 40 caps per minute. CapMaster Controller, Model C302E, 120 AC Volts, Baldor Motor, 1/4 hp, 90 volts, 2.7 amps, 1,750 rpm. The model C300 is a cycle on demand machine that waits for the operator to place the container against a V-block switch in order to start the cycle. The machine automatically stops at the end of the cycle and the operator removes the container. All Bench top cappers feature an easy height adjustment crank handle. The crank is part of a rack and pinion height adjustment system that allows for height adjustment for up to 13 inch tall containers. Overall dimensions: 23 in. L x 12 in. W x 35 in. H.



SWAN-MATIC

Bottle Capping Machines & Equipment

[HOME](#) [PRODUCTS](#) [LIBRARY](#) [CONTACT](#)

The model C300 is a cycle on demand machine that waits for the operator to place the container against a V-block switch in order to start the cycle. The machine automatically stops at the end of the cycle and the operator removes the container. The C300 includes a variable speed motor and will produce more than 40 cappings at factory settings.



All Benchtop cappers feature an Easy Height Adjustment Crank Handle



(Click image for details)

LOOKING FOR PORTABILITY?

The C650 Capping carts provides the ability to take the machine to the work rather than the work to the machine. [\[More Info\]](#)



[Instructions \(PDF\)](#)

[Standard Features](#)

[Safety Features](#)

[Basic Operation \(PDF\)](#)

[Basic Dimensions](#)

[Available Options:](#)

- [Reversing Switch](#)
- Foot Switches
- Extended (Taller) Column
- [Coatings / Plating](#)
- 50Hz or 60Hz Operation
- [Precise Torque Capper Clutch](#)

Customization Available Upon Request

Model Number	Input	Main Feature
C300.1	120 Volts	Single Cycle: operates on- demand
C300.2	240 Volts	




SWAN-MATIC

Bottle Capping Machines & Equipment

[HOME](#) [PRODUCTS](#) [LIBRARY](#) [CONTACT](#)

Basic Capper Dimensions



Approx. Ship Weight: 127 lbs.

Standard Carton Size: 17" W x 28" L x 40" H

All electric benchtop models are available for 50Hz and 60Hz operation. The following are options which can be added to enhance machine operation and/or performance:

- Spindle reversing feature to facilitate de-capping
- Longer columns for up to 15 inch containers
- Foot switch for hands-free operation
- Stainless steel shaft and clutch assemblies
- Precision magnetic hysteresis clutch (accurate to 0.1 in-lbs)
- Special coatings and plating
- Hazardous location motors Adjustable height cart Corrosion resistant finish

Automation Devices, Inc.

SWAN-MATIC CAPPER INSTRUCTIONS

➤ **SETUP & OPERATION**

Carefully unpack the Capper and any other associated equipment which may be in the container. Set the machine on a level surface and remove the dipstick located on the top left rear of the capper head. Add the two quarts of Gear Oil (E.P. SAE 80w90 P/N C095) supplied into the housing through the dipstick hole. The oil level will show on the bottom of the dipstick indicating the correct level. **The capacity is two quarts Maximum.**

Attach the proper sized driver shell with a rubber insert on the lower end of the clutch and fasten it securely with the wrenches provided. Connect power to the electric motor (after checking to make sure that the voltage marked on the nameplate is the same as the power supply to which the capper will be connected). Run the capper for several minutes at room temperature to thoroughly lubricate the mechanism. The capper should run free and easy with no effort. If it does not, inspect the capper for shipping damage.

Accurate alignment of the container cap to the insert and proper height and torque settings are critical for optimum capping results. Rotate the spindle until it reaches the bottom of its stroke. Place an already capped container under the insert, adjusting the capper height so that the container cap just contacts the insert. The height is adjusted by loosening the column locking handle and moving the capper up or down on the column. With the capped container directly under the insert, slide the backstop assembly up against the container and tighten. Rotate the spindle until you can remove the container. Readjust the capper height directly down - $\frac{1}{8}$ to $\frac{1}{4}$ inch (depending on the dimensions of the cap and container) to allow for overtravel. Securely tighten the column locking handle.

TORQUE ADJUSTMENT

Adjust the clutch to set the capper for the desired torque. Hold the clutch cap (the upper section), either by hand or by using the wrench supplied, and loosen the center lock ring several turns. To increase the torque, turn the lower clutch section **into** the clutch cap. To decrease the torque, back the lower section **away from** the clutch cap. When the proper torque setting has been obtained, tighten the center lock ring to retain the setting.

NOTE: The shell and clutch should always stop momentarily near the end of each stroke when contact is made with the cap. Excessive rotation after contact may cause premature insert wear and damage to the cap.

MAINTENANCE

Periodic inspection of the oil level in the capper head housing is recommended to ensure that sufficient lubrication is present. We recommend E.P. SAE 80/90 weight gear oil (our P/N C095) or equivalent. Approximately once every six months, it is recommended that the clutch be disassembled, cleaned, and a good grade of grease be applied to the clutch lining to ensure long life and consistent torque. Excessive grease may seep out of the clutch during operation.

➤ **REPLACING SPINDLE OIL SEAL**

Always exercise extreme caution when removing the shaft seal to ensure the shaft itself is not permanently marked or scored.

Unscrew and remove the lower section of the clutch from the clutch cap (upper section). This will expose a bearing on the lower end of the spindle shaft. This bearing is held in place with a snap ring on the under side. Remove the snap ring and press the bearing downward to remove the bearing from the spindle.

The fiber clutch cone is held in place with a $\frac{3}{16}$ " diameter roll pin. In removing the roll pin, be sure to use a punch of the proper diameter. **Be careful to support the spindle shaft to assure that it is not damaged or bent.** After the roll pin is removed, the fiber cone and the remaining clutch parts can be removed from the spindle. **The factory recommends draining the oil before removing the seal to prevent oil loss.** The shaft seal can be removed by puncturing the *metal section* on the lower side of the seal and then prying the seal out of its seat. The seal can also be removed by drilling several small holes in the metal section of the seal, inserting sheet metal screws part way in, and then prying the seal out.

After removing the seal from its seat, thoroughly clean the seat and shaft to remove all oil and foreign material. Inspect the shaft for score marks which could cause premature seal failure. If any marks cannot be removed by polishing the spindle, replacement may be required. If this is the case, contact the factory for parts and the proper procedure.

Before installing the new shaft seal, it is recommended that the lower end of the spindle shaft be covered with a *thin coating of oil*. This will allow the shaft seal to slide along the shaft without damaging the seal. **The seal should be installed with the open side up.** Before seating the seal, apply a layer of gasket sealer (i.e., Permatex or equivalent - our P/N C111) to the seat.

Gently tap the shaft seal into place with a hammer and a block of wood. Make sure that the shaft seal is not misaligned and bound in the casting before attempting to seat it.

Replace the clutch in a reverse manner from how it was removed. Lubricate the clutch face with a good grade of bearing grease (such as Lubriplate or equivalent).

IMPORTANT

The capper is shipped without oil. The two quarts supplied with the machine must be added to the machine before operating. **If the capper is to be returned for repair, the oil must be drained.** A socket head drain plug is located behind the spindle in the underside of the housing.

REPLACEMENT PARTS

When ordering replacement parts, specify both the part number from the parts list and the serial number on the capper.

IN01.01

In USA: Automation Devices, Inc.

7050 West Ridge Road
Fairview, PA 16415-2099
Phone: 814-474-5561

FAX: 814-474-2131 or 800-235-9382

Web Site: www.autodev.com E-mail: info@autodev.com

In Canada: Automation Devices (Canada) Ltd.

4700 Montrose Road
Niagara Falls, Ontario L2H 1K3
Phone: 905-354-3881

FAX: 905-354-4072

Email: sales@adlcan.com