


File: SERVICE MANUAL - Section 070
Replaces: NOTHING
Dist: 3, 3a, 3b, 3c
Revised: April 2016, p. 2, 8, 16

TDS_ ROTARY SCREW COMPRESSOR

MODELS TDS_163 - TDS_355



**THIS MANUAL CONTAINS RIGGING, ASSEMBLY, START-UP,
AND MAINTENANCE INSTRUCTIONS. READ THOROUGHLY
BEFORE BEGINNING INSTALLATION. FAILURE TO FOLLOW THESE
INSTRUCTIONS MAY RESULT IN PERSONAL INJURY OR DEATH,
DAMAGE TO THE UNIT, OR IMPROPER OPERATION.**

CONTENTS

GENERAL INFORMATION	
PREFACE	3
DESIGN LIMITATIONS	3
JOB INSPECTION	3
STANDARD BARE COMPRESSOR	3
TRANSIT DAMAGE CLAIMS	3
COMPRESSOR IDENTIFICATION	3
LONG TERM STORAGE	4
PREPARING COMPRESSOR FOR STORAGE	5
MAINTAINING COMPRESSOR.....	5
DESCRIPTION	5
TDS_ COMPRESSOR	5
COMPRESSOR LUBRICATION SYSTEM	5
OIL PUMP.....	6
CONSTRUCTION DETAILS	6
INSTALLATION	
DESIGN LIMITS	7
OUTLINE DIMENSIONS	7
HOLDING CHARGE AND STORAGE.....	12
RIGGING AND HANDLING.....	12
FOUNDATION	12
CUSTOMER CONNECTIONS.....	13
OIL SYSTEM REQUIREMENTS	13
OIL SELECTION	13
OIL PRESSURE	13
OIL COOLING REQUIREMENTS	13
OIL FILTER(S)	13
OIL PUMP.....	13
OIL HEATER(S)	14
COMPRESSOR OIL.....	14
COMPRESSOR.....	14
COMPRESSOR ROTATION.....	14
MOTOR MOUNTING (FOOT MOUNTED ONLY).....	14
COMPRESSOR/MOTOR COUPLING REQUIREMENTS. ...	14
COUPLING ALIGNMENT REQUIREMENTS.....	14
COUPLING ALIGNMENT PROCEDURE.....	14
HOT ALIGNMENT OF COMPRESSOR/MOTOR	14
SV POSITION POTENTIOMETER REPLACEMENT AND ADJUSTMENT.....	15

VOLUMIZER POTENTIOMETER REPLACEMENT AND ADJUSTMENT	15
COMPRESSOR HYDRAULIC SYSTEM	16
VOLUMIZER VOLUME RATIO CONTROL	16
Vi Increase	16
Vi Decrease	16
LOW AMBIENT OPERATION	17
BALANCE PISTON PRESSURE REGULATOR FOR TDSH 355 COMPRESSORS.....	17

OPERATION	
OPERATION AND START-UP INSTRUCTIONS	18
INITIAL START-UP	18
INITIAL START-UP PROCEDURE	18
NORMAL START-UP PROCEDURE	18

MAINTENANCE	
GENERAL INFORMATION	19
NORMAL MAINTENANCE OPERATIONS	19
CHANGING OIL	19
RECOMMENDED MAINTENANCE PROGRAM	19
VIBRATION ANALYSIS	19
OIL QUALITY AND ANALYSIS	20
OPERATING LOG	20
TROUBLESHOOTING GUIDE	21
ABNORMAL OPERATION ANALYSIS & CORRECTION ...	21
BARE COMPRESSOR REPLACEMENT	21
SHUTDOWN DUE TO IMPROPER OIL PRESSURE	21
TROUBLESHOOTING THE HYDRAULIC SYSTEM.....	22
TROUBLESHOOTING THE OIL PUMP AND SYSTEM	23
VIBRATION DATA SHEET.....	26

Referenced manuals:

090.020-M	Quantum LX Maintenance
160.802-SPC	Compressor Oil Specifications
090.022-O	Quantum HD Operation

SAFETY PRECAUTION DEFINITIONS

 DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a potentially hazardous situation or practice which, if not avoided, will result in death or serious injury.
 CAUTION	Indicates a potentially hazardous situation or practice which, if not avoided, will result in damage to equipment and/or minor injury.
NOTICE	Indicates an operating procedure, practice, etc., or portion thereof which is essential to highlight.

THE INFORMATION CONTAINED IN THIS
DOCUMENT IS SUBJECT TO CHANGE
WITHOUT NOTICE

GENERAL INFORMATION

PREFACE

This manual has been prepared to acquaint the owner and serviceman with the INSTALLATION, OPERATION, and MAINTENANCE procedures as recommended by Johnson Controls-Frick for tds_ Rotary Screw Compressors.

It is most important that these compressors be properly applied to an adequately controlled refrigerant or gas system. Your authorized Johnson Controls-Frick representative should be consulted for his expert guidance in this determination.

Proper performance and continued satisfaction with these units is dependent upon:

**CORRECT INSTALLATION
PROPER OPERATION
REGULAR, SYSTEMATIC MAINTENANCE**

To ensure correct installation and application, the equipment must be properly selected and connected to a properly designed and installed system. The Engineering plans, piping layouts, etc. must be detailed in accordance with the best practices and local codes, such as those outlined in ASHRAE literature.

A screw compressor is a VAPOR PUMP. To be certain that it is not being subjected to pumping liquid, it is necessary that controls are carefully selected and in good operating condition; the piping is properly sized and traps, if necessary, are correctly arranged; the suction line has an accumulator or slugging protection; that load surges are known and provisions are made for control; operating cycles and stand still periods are reasonable; and that high side components are sized within system and compressor design limits.

It is required that the discharge temperature be kept high enough to prevent condensation of any moisture in the compressor and oil separator.

DESIGN LIMITATIONS

TDS_ compressors are designed for operation within the pressure and temperature limits which are specified by Johnson Controls-Frick and the Johnson Controls-Frick selection software COOLWARE™. They are primarily used for compressing refrigerant gas and most hydrocarbon gasses.

If your application is for sour gas, there are special requirements to protect the compressor. Contact Johnson Controls - Frick Compressor Engineering for application details.

JOB INSPECTION

Immediately upon delivery examine all crates, boxes and exposed compressor and component surfaces for damage. Unpack all items and check against shipping lists for any discrepancy. Examine all items for damage in transit.

STANDARD BARE COMPRESSOR

Items not included with bare compressor that are available as sales order options: Solenoid Valves, Tank Drain Tubing (T connection), Oil Feed Line (P connection), Connection Fittings, Coupling.

TRANSIT DAMAGE CLAIMS

All claims must be made by consignee. This is an ICC requirement. Request immediate inspection by the agent of the carrier and be sure the proper claim forms are executed. Report damage or shortage claims immediately to Johnson Controls-Frick Sales Administration Department, in Waynesboro, PA.

COMPRESSOR IDENTIFICATION

Each compressor has an identification data plate, containing compressor model and serial number mounted on the compressor body.

NOTICE

When inquiring about the compressor or unit, or ordering repair parts, provide the MODEL, SERIAL, and JOHNSON CONTROLS - FRICK SALES ORDER NUMBERS from the data plate. See Figure 1.

Frick
BY JOHNSON CONTROLS

ROTARY SCREW COMPRESSOR

MODEL NO. PART NO.

SERIAL NO.

MAX ALLOWABLE PRESSURE - PSIG MAX DRIVER SPEED - RPM

MADE IN

Figure 1. Compressor Identification Data Plate

Rotary screw compressor serial numbers are defined by the following information:

EXAMPLE: 10240A90000015Z

PLANT	DECADE	MONTH	YEAR	GLOBAL SEO NO.	ADDITIONAL REMARKS
1024	0	A	9	0000015	Z

Plant: 1024 = Waynesboro, 1153 = Monterrey

Month:

A = JAN, B = FEB, C = MAR, D = APR, E = MAY, F = JUN, G = JUL, H = AUG, K = SEP, L = OCT, M = NOV, N = DEC.

Additional Remarks:

R = Remanufactured;
R1 = Rebuild;
R2 = Rebuild Plus;
Z = Deviation from Standard Configuration.

Long term storage of equipment may lead to the deterioration of components over the period of time. Synthetic components in the compressor may deteriorate over time even if they are kept flooded with oil. A warm and dry environment is essential to minimize environmental and corrosion damage. Long term storage of the affected equipment at a customer's site may involve additional requirements and interested parties should refer to the Johnson Controls web site, www.johnsoncontrols.com/frick, for specific instructions (Location: Bare Compressors\General\Warranties\Screw Compressor Purchased for Long Term Storage).

The following guidelines must be followed to maintain the SCREW COMPRESSOR WARRANTY.

PREPARING COMPRESSOR FOR STORAGE

Evacuate compressor to remove moisture. Evacuation lines are to be connected to port SM1. Evacuation lines are to be connected to the three Schrader valves provided with the compressor. One valve is connected to compressor suction. The other two valves are located at the block on the cylinder.

Break vacuum with dry nitrogen and bring pressure to 0 psig.

Pump oil into the same ports mentioned in step 1. Johnson Controls-Frick recommends break-in oil P/N 111Q0831809 for storage purposes. The amounts of oil needed per compressor are:

- 163mm - 8Gal
- 193mm - 12Gal
- 233mm - 15Gal
- 283mm - 25Gal
- 355mm - 35Gal

After compressor is oil charged, pressurize compressor to 15 psig with nitrogen.

MAINTAINING COMPRESSOR

Ensure that the 5-15 psig nitrogen charge is maintained with 15 psig preferred.

Rotate the male rotor shaft every two weeks. Mark the shaft to ensure the rotor does not return to the original position.

The compressor must be stored inside a dry building environment.

Grease the male rotor shaft to prevent rust.

Record all information in a "Compressor Long Term Storage Log." See bottom of page 4.

Contact Johnson Controls-Frick Service with any questions regarding long term storage.

DESCRIPTION

TDS_ COMPRESSOR

The Frick TDS_ rotary screw compressor utilizes mating asymmetrical profile helical rotors to provide a continuous flow of refrigerant vapor and is designed for both high pressure and low pressure applications. The compressor incorporates the following features:

1. High capacity roller bearings to carry radial loads at both the inlet and outlet ends of the compressor.
2. Heavy-duty, two-point or four-point angular contact ball bearings to carry axial loads are mounted at the discharge end of compressor.
3. Balance piston located in the inlet end of the compressor to reduce axial loads on the axial load bearings and increase bearing life.
4. Moveable slide valve to provide infinite step capacity control from 100 to 10%.
5. VOLUMIZER volume ratio control to allow infinitely variable volume ratio from 2.2 to 5.0 during compressor operation for all models except TDSH 283SX which is 2.2 to 4.2.
6. A hydraulic unloader cylinder to operate the slide stop and slide valve.
7. Bearing and casing design for 400 PSI discharge pressure. This PSI rating applies only to the compressor and does not reflect the design pressure of the various system components.
8. All bearing and control oil vented to closed thread in the compressor instead of suction port to avoid performance penalties from superheating suction gas.
9. Shaft seal design to maintain operating pressure on seal well below discharge pressure, for increased seal life.
10. Oil injected into the rotors to maintain good volumetric and adiabatic efficiency even at very high compression ratios.
11. Shaft rotation clockwise facing compressor shaft, suitable for all types of drives. **SEE WARNING.**

WARNING

Compressor rotation is clockwise when facing the compressor drive shaft. The compressor should never be operated in reverse rotation, as bearing damage will result.

12. Dual compressor casing design for very low airborne noise transmission.

COMPRESSOR LUBRICATION SYSTEM

The lubrication system on a TDS_ screw compressor performs several functions:

1. Provides lubrication to bearings and seal.
2. Provides a cushion between the rotors to minimize noise and vibrations.
3. Helps keep the compressor cool and prevents overheating.
4. Provides an oil supply to hydraulically actuate the slide valve and slide stop.
5. Provides oil pressure to the balance piston to help increase bearing life.
6. Provides an oil seal between the rotors to prevent rotor contact or gas bypassing.

OIL PUMP

A demand oil pump is required for low differential pressure applications (CoolWare™ will provide a warning when the oil differential pressure is too low). Oil being supplied to the compressor from the oil separator is at system discharge pressure. Within the compressor, oil porting to all parts of the compressor is vented back to a location in the compressor's body that is at a pressure lower than compressor discharge pressure. All oil entering the compressor is moved by the compressor rotors out the compressor outlet and back to the system oil separator.

CONSTRUCTION DETAILS

HOUSING: All TDS_ screw compressor castings are close grain, pressure tight, grey cast iron to ensure structural integrity and mechanical and thermal stability under all operating conditions. Ductile iron and steel housings are also available for special applications. Contact Johnson Controls – Frick Sales for additional information.

ROTORS: The rotors are made from the highest quality rolled steel to exacting tolerances of the latest industry standard asymmetric profile. The four-lobed male rotor is directly connected to the driver. The six-lobed female rotor is driven by the male on a thin oil film.

BEARINGS: Antifriction bearings with L₁₀ rated life in excess of 50,000 hours (using the Frick Superfilter™) at design conditions are used for reduced frictional horsepower and superior rotor positioning, resulting in reduced power consumption, particularly at higher pressure ratios. Cylindrical roller bearings are provided to handle the radial loads and the thrust loads are absorbed by two-point or four-point angular contact bearings. In addition, a thrust balance piston is provided to reduce the thrust load and improve bearing life.

SHAFT SEAL: The compressor shaft seal is a single-face type with a spring-loaded carbon stationary surface riding against a cast iron rotating seat. The seal is capable of withstanding static pressure up to 400 psig. During operation it is vented to low pressure to provide extended life.

VOLUMIZER VARIABLE VOLUME RATIO CONTROL: The Frick compressor includes a method of varying the internal volume ratio to match the system pressure ratio. Control of the internal volume ratio eliminates the power penalty associated with over- or under-compression. Volume ratio control is achieved by the use of a slide stop which is a movable portion of the rotor housing that moves axially with

the rotors to control discharge port location. The slide stop is moved by hydraulic actuation of a control piston. The range of adjustment is listed in the *COMPRESSOR VOLUME and CAPACITY RATIO* table.

STEPLESS CAPACITY CONTROL: Capacity control is achieved by use of a movable slide valve. The slide valve moves axially under the rotors to provide fully modulated capacity control from 100% to minimum load capacity. Minimum load capacity varies slightly with compressor model, pressure ratio, discharge pressure level, and rotor speed. See the TABLE 1 for minimum capacity for all TDS_ models.

The slide valve is positioned by hydraulic movement of its control piston. When in the unloaded position, gas is bypassed back to suction through a recirculation slot before compression begins and any work is expended, providing the most efficient unloading method available for part-load operation of a screw compressor.

Table 1. COMPRESSOR VOLUME and CAPACITY RATIO

MODEL	MIN VI*	MAX VI*	MIN. CAPA-CITY %	SLIDE VALVE TRAVEL (IN.)	SLIDE STOP TRAVEL (IN.)
TDSH 163S	2.2	5.0	REFER TO COOLWARE™	5.494	2.140
TDSH 163L	2.2	5.0		6.918	2.694
TDSH 193S	2.2	5.0		6.497	2.530
TDSL 193L	2.2	5.0		8.662	3.374
TDSH 233S	2.2	5.0		7.843	3.055
TDSH 233L	2.2	5.0		9.877	3.847
TDSH 233XL	2.2	5.0		9.889	4.752
TDSH 283S	2.2	5.0		9.526	3.710
TDSH 283L	2.2	5.0		11.996	4.672
TDSH 283SX	2.2	4.2		11.951	4.680
TDSH/B 355S	2.2	5.0		10.360	5.690
TDSH/B 355L	2.2	5.0		14.127	5.031
TDSH/B 355XL	2.2	5.0		15.443	6.373
TDSB 355U	2.4	4.5		15.482	6.399

* Optional 1.7 MIN - 3.0 MAX.

INSTALLATION

DESIGN LIMITS

General information for all of the models is provided below. **Please see CoolWare to determine the limits for a specific application.**

TDS_ units are arranged for direct motor drive and require a flexible drive coupling to connect the compressor to the motor. The rotor and bearing design set limitations must not be exceeded (See CoolWare). Refer to Johnson Controls - Frick Compressor Control Panel instruction 090.022-O for additional information on setpoint limits.


OUTLINE DIMENSIONS

Drawings *for reference only* can be found on the following pages. Complete dimensions and access connections can be found on the outline drawings.

TDSH 163	DWG# 534E0424
TDSH 193	DWG# 534E0425
TDSL 193	DWG# 534E0591
TDSH 233 1.35 & 1.7	DWG# 534D0224
TDSH 233 2.1	DWG# 534E0499
TDSL 233	DWG# 534D1025
TDSH 283 1.35 & 1.7	DWG# 534E0054
TDSH 283 2.1	DWG# 534E0605
TDSL 283 1.35 & 1.7	DWG# 534E0582
TDSL 283 2.4	DWG# 534E0583
TDXB 355 S, L, XL, U	DWG# 534E1406
TDXH 355 S, L, XL, U	DWG# 534E1406


If you do not have these drawings, please request any you require by contacting Johnson Controls - Frick sales.

COMPRESSOR PORT LOCATIONS - 163/193




SYMBOL	SIZE
SC-1	3/8-18 NPTF
SC-2	3/8-18 NPTF
SC-3	3/8-18 NPTF
SC-4	3/8-18 NPTF
SC-5	3/8-18 NPTF
SC-6	3/8-18 NPTF
SC-7	1/8-27 NPTF
SC-8	1-11½ NPTF
SC-9	3/8-18 NPTF
SC-10	3/4-14 NPTF
SC-11	3/4-14 NPTF
SC-13	3/8-18 NPTF
SB-2	3/8-18 NPTF
SB-3	3/4-14 NPTF
SM-1	3/8-18 NPTF
SV-1	1¼ SQ FLANGE
SL-1	3/4-14 NPTF
SL-2	3/4-14 NPTF
SE-1	1/2-14 NPTF
SE-2	1/2-14 NPTF
SD-1	3/4-16 UNF-2B

COMPRESSOR PORT LOCATIONS - 233




SYMBOL	SIZE
SB-2	3/8-18 NPTF
SB-3	3/4-14 NPTF
SC-1	3/8-18 NPTF
SC-2	3/8-18 NPTF
SC-3	3/8-18 NPTF
SC-4	3/8-18 NPTF
SC-5	3/8-18 NPTF
SC-6	3/8-18 NPTF
SC-7	1/8-27 NPTF
SC-8	1-11½ NPTF
SC-9	3/8-18 NPTF
SC-10	3/4-14 NPTF
SC-11	3/4-14 NPTF
SC-12	3/8-18 NPTF
SD-1	1½-12 UN-2B
SL-1	3/4-14 NPTF
SL-2	3/4-14 NPTF
SM-1	3/4-14 NPTF
SV-1M	1½ SQ FLANGE

COMPRESSOR PORT LOCATIONS - TDS_ 283



SYMBOL	SIZE
SB-2	3/4-14 NPTF
SB-3	1-11½ NPTF
SC-1	3/8-18 NPTF
SC-2	3/8-18 NPTF
SC-3	3/8-18 NPTF
SC-4	1/2-14 NPTF
SC-5	3/8-18 NPTF
SC-6	3/8-18 NPTF
SC-7	1/8-27 NPTF
SC-8	1-11½ NPTF
SC-9	1¼-11½ NPTF
SD-1	1¼-12 UN-2B
SL-1	1-11½ NPTF
SL-2	1-11½ NPTF
SM-1	1-11½ NPTF
ST-1	2 SQ FLANGE

COMPRESSOR PORT LOCATIONS - TDS_ 355



HOLDING CHARGE AND STORAGE

Every TDS_ compressor is pressure and leak tested at the Johnson Controls-Frick factory and then thoroughly evacuated and charged with dry nitrogen to ensure its integrity during shipping and short term storage prior to installation.

All compressors must be kept in a clean, dry location to prevent corrosion damage. Compressors that will be stored for more than two months must have their nitrogen charge checked periodically (see pages in GENERAL INFORMATION for complete instructions).

⚠ WARNING
<p>Holding-charge shipping gauges (if mounted) are rated for 30 psig and are for checking the shipping charge only. They must be removed before pressure testing and operating the system. Failure to remove these gauges may result in catastrophic failure of the gauge resulting in serious injury or death.</p> <p>Access valves are bronze and they must be replaced with steel plugs when package is assembled.</p>

⚠ CAUTION
<p>THIS EQUIPMENT HAS BEEN PRESSURIZED WITH NITROGEN GAS. TEMPORARY VALVES AND GAUGES HAVE BEEN INSTALLED.</p> <ol style="list-style-type: none"> RELIEVE PRESSURE PRIOR TO OPENING LINES OR MAKING FIELD CONNECTIONS. REMOVE CHARGING VALVES OR GAUGES PRIOR TO PRESSURIZING SYSTEM. REFER TO INSTALLATION OPERATION AND MAINTENANCE MANUAL FOR ADDITIONAL INFORMATION. <p style="text-align: center;">ESCAPING GAS MAY CAUSE INJURY.</p>

RIGGING AND HANDLING

The compressor can be moved with rigging, using a crane or forklift, by hooking into the two lifting rings on the main housing (some models only have one ring). The compressor lifting rings shall only be used to lift the compressor itself. See Figure 3.




Figure 3. Lifting Rings, Model 355

FOUNDATION

Each TDS_ Rotary Screw Compressor is shipped mounted on a wooden skid, which must be removed prior to unit installation.

⚠ CAUTION
<p>Allow proper spacing for servicing (see Dimensional Outline Drawing).</p>

The first requirement of the compressor foundation is that it must be able to support the weight.

163S	1,220 lb	233S	2,670 lb
163L	1,280 lb	233L	2,950 lb
193S	1,720 lb	233XL	3,300 lb
193L	1,895 lb	283S	4,100 lb
355S	7,200 lb	355XL	9,200 lb
355L	8,240 lb	355U	10,200 lb

Screw compressors are capable of converting large quantities of shaft power into gas compression in a relatively small space. The compression process creates relatively high frequency vibrations that require sufficient mass in the base to effectively dampen them.

The best insurance for a trouble-free installation is to firmly anchor the compressor to a suitable foundation using proper bolting and by preventing piping stress from being imposed on the compressor. Once the compressor is rigged into place, its feet must be shimmed to level it. There must be absolutely no stresses introduced into the compressor body due to bolting of the feet and flanges.

In any screw compressor installation, suction and discharge lines should be supported in pipe hangers (preferably within 2 feet of vertical pipe run) so that the lines won't move if disconnected from the compressor. See table for Allowable Flange Loads.

NOZ. SIZE NPS	ALLOWABLE FLANGE LOADS					
	MOMENTS (ft-lbf)			LOAD (lbf)		
	AXIAL	VERT.	LAT.	AXIAL	VERT.	LAT.
	M _R	M _C	M _L	P	V _C	V _L
1	25	25	25	50	50	50
1.25	25	25	25	50	50	50
1.5	50	40	40	100	75	75
2	100	70	70	150	125	125
3	250	175	175	225	250	250
4	400	200	200	300	400	400
5	425	400	400	400	450	450
6	1,000	750	750	650	650	650
8	1,500	1,000	1,000	1,500	900	900
10	1,500	1,200	1,200	1,500	1,200	1,200
14	2,000	1,800	1,800	1,700	2,000	2,000

Table 4. Allowable Flange Loads

CUSTOMER CONNECTIONS

As a minimum you must connect to the following locations in addition to suction and discharge.

SB-2	Inlet Bearings and Balance Piston
SB-3	Compressor oil supply
SM-1	Main oil injection
SC-1	Slide Valve Unload Port
SC-2	Slide Valve Load Port
SC-3	Volume Ratio Increase Port
SC-4	Volume Ratio Decrease Port
SD-1	Coalescer Bleed

Other connections are available for instrumentation and service as noted on the Dimensional Outline drawing. The electrical connections for the slide stop and the slide valve transmitters and the solenoid valve coils must be connected to your control system.

The oil supply system for the compressor must be designed for a total pressure drop of no more than 15 psi with a new oil filter element. This is critical for the proper operation of the balance piston which is used to ensure the life of the male axial bearing. Excessive pressure drop in the oil circuit can also prevent proper operation of the slide valve and slide stop pistons.

OIL SYSTEM REQUIREMENTS



Figure 4. Caution/Identification Tag on Access Valve

The oil system must provide oil to the compressor within limitation on:

- Oil selection
- Oil pressure
- Oil temperature
- Oil cleanliness

OIL SELECTION

The selected oil must be suitable for the application, refrigerant and operation condition. The compressor bearing require a minimum viscosity based on size and speed, rpm. A maximum viscosity of 100 cSt should not be exited. Frick compressor oils per 160.802-SPC are recommended. Frick Coolware compressor selection program include properties for the Frick oils and provide information on viscosity requirement for a given compressor selection.

OIL PRESSURE

The complete oil system shall be designed for a pressure drop no higher than 15 psi with a clean oil filter element. These is critical for the proper function of the balance piston and ensure the life of the axial bearings. At booster, low pressure and low pressure ratio operation an oil pump must be build in to provide sufficient oil pressure.

The control system should have means to check the oil pressure and compare to both suction and discharge pressure. In general oil pressure shall be minimum (1.5 times the suction pressure +15 psi) and higher than (discharge pressure - 25 psi). For application with economizer and/or side-load the oil pressure shall additional be more than 15 psi above the pressure at the side port when in operation.

Advanced control systems like the Frick Quantum will check on the oil pressure in many more ways in order to keep the compressor running beyond these basic limits e.g. keep compressor running safely in partial loaded condition.

OIL COOLING REQUIREMENTS

Compressor oil needs to be cooled to control the discharge temperature, maintain proper oil viscosity and to preserve the life of the oil. Normally the discharge temperature will be in the 170° - 180°F range (see CoolWare™).

One application that typically requires higher discharge temperatures (as high as 250°F) is natural gas gathering at the wellhead. Moisture is normally present in the gas and it is imperative that the discharge temperature be at least 40°F higher than the discharge dew point temperature for the gas. Run Coolware with the "Water Saturated" block checked to get the discharge dew point temperature for your application. Oil temperatures as high as 170°F can be used to achieve the necessary discharge temperature to prevent moisture from condensing in the oil separator. Contact Johnson Controls-Frick for additional information for natural gas compression.

The main oil injection line that is connected to port SM1 must have a regulating valve to permit adjustment of the oil flow to maintain the desired discharge temperature at all times.

The use of a three-way mixing valve is recommended to keep the oil temperature in the normal range of 120° - 140°F. The valve will provide warm oil to the compressor quickly, reducing the pressure drop caused by cold, viscous oil. This ensures proper oil flow and temperature over the full range of operating conditions.

OIL FILTER(S)

Use of filter elements other than Johnson Controls-Frick must be approved in writing by Johnson Controls-Frick engineering or a warranty claim may be denied. Typical oil filter specification is 5 micron absolute (98.6% effecient) per ISO 4572 to obtain the recommended oil cleanliness.

OIL PUMP

If your TDS_ compressor application requires an oil pump, it is recommended that a strainer be mounted upstream to protect it. Frick supplied pumps are a positive displacement gear type that must have a safety relief valve to ensure the

oil pressure will not be more than 50 psi above compressor discharge pressure for all models.

⚠ CAUTION

If oil pressure exceeds 55 PSI above compressor discharge it could cause catastrophic compressor failure due to male axial bearing failure. See CoolWare™ for your application's requirements.

OIL HEATER(S)

Your package must be equipped with oil heaters that provide sufficient heat to prevent condensation from occurring during shutdown cycles.

COMPRESSOR OIL

⚠ WARNING

DO NOT MIX OILS of different brands, manufacturers, or types. Mixing of oils can cause excessive oil foaming, nuisance oil level cutouts, oil pressure loss, gas or oil leakage and catastrophic compressor failure. For most applications, CoolWare will select a specific Frick oil for the gas/refrigerant being used. Depending on the application, a different oil can be selected provided it is of the proper viscosity and is compatible with the gas/refrigerant and compressor elastomers.

COMPRESSOR

COMPRESSOR ROTATION IS CLOCKWISE WHEN FACING THE END OF THE COMPRESSOR SHAFT

Confirm motor will rotate the compressor clockwise before installing the coupling.

MOTOR MOUNTING (FOOT MOUNTED ONLY)

1. Thoroughly clean the motor feet and mounting pads of grease, burrs, and other foreign matter to ensure firm seating of the motor.
2. Attach the motor to the base using bolts and motor raising blocks, if required.
3. Weld the four kick bolts (not included with compressor) into place so that they are positioned to allow movement of the motor feet.
4. After the motor has been set, check to see that the shafts are properly spaced for the coupling being used. Check the appropriate Dimensional Outline drawing for the minimum clearance required between the shaft ends to change the shaft seal.

COMPRESSOR/MOTOR COUPLING REQUIREMENTS.

Frick TDS_ compressors are arranged for direct motor drive and require a flexible drive coupling to connect the compressor to the motor.

With a foot-mounted motor, it is essential that the coupling be properly aligned to ensure proper bearing and seal performance.

1. Coupling must be selected and installed so that it doesn't transmit any axial load to the compressor shaft.
2. Set up the minimum distance between compressor shaft and motor shaft to allow for seal removal (see Outline drawings).

3. Coupling must be able to take up any misalignment between motor and compressor. It is critical to the life of the shaft seal that misalignment is kept to the minimum possible value. Be sure to follow the coupling manufacturer's guidelines for checking and correcting any misalignment. See the next section for Johnson Controls-Frick requirements.

COUPLING ALIGNMENT REQUIREMENTS

Coupling alignment must be performed prior to start-up. After the compressor has been installed on the job site, alignment must be checked again and if necessary corrected prior to start-up. After a few hours operation, the alignment must be checked while the package is still hot. Correct hot alignment is critical to ensure the life of the shaft seal and compressor bearings.

**Maximum radial runout is .004" total indicator reading.
Maximum axial runout is .004" total indicator reading.**

A dial indicator or another appropriate measuring device is to be used to determine the Total Indicator Runout.

Indicator bracket sag must be checked as all brackets have some flexibility. The best way to measure this is to attach the dial indicator and bracket on a pipe at the coupling span distance. Zero the indicator in the 12:00 position, and rotate the pipe so the indicator is in the 6:00 position. The reading on the indicator in the 6:00 position is the bracket sag. This value must be included in the dial indicator readings when affixed to the coupling for an accurate alignment.

COUPLING ALIGNMENT PROCEDURE

The life of the compressor shaft seal and bearings, as well as the life of the motor bearings, is dependent upon proper coupling alignment. Couplings may be aligned at the factory but realignment **MUST ALWAYS** be done on the job site after the unit is securely mounted on its foundation. Initial alignment must be made prior to start-up and rechecked after a few hours of operation. Final (HOT) field alignment can only be made when the unit is at operating temperature. After final (HOT) alignment has been made and found to be satisfactory for approximately one week, the motor may be dowelled to maintain alignment.

NOTICE

Frick recommends cold aligning the motor .005" high. This cold misalignment compensates for thermal growth when the unit is at operating temperature.

HOT ALIGNMENT OF COMPRESSOR/MOTOR

Hot alignments can only be made after the unit has operated for several hours and all components are at operating temperatures.

Shut down the unit and quickly affix dial indicator to coupling motor hub, then take readings of both the face and rim of the compressor hub. If these readings are within tolerance, record reading, attach coupling guard and restart unit. However, if the reading is not within limits, compare the hot reading with the cold alignment and adjust for this difference; i.e. if the rim at 0° and 180° readings indicates that the motor rises .005" between its hot and cold state, .005" of shims should be removed from under the motor.

After the initial hot alignment adjustment is made, restart unit and bring to operating temperature. Shut down and recheck hot alignment. Repeat procedure unit hot alignment is within specified tolerance.

⚠ CAUTION

INSTALL COUPLING GUARD BEFORE OPERATING COMPRESSOR.

SV POSITION POTENTIOMETER REPLACEMENT AND ADJUSTMENT

The Slide Valve Position potentiometer is located on the end of the compressor unloader cylinder (see Figure 4).




Figure 5. Potentiometer

1. Shut off control power.
2. Remove the four socket head cap screws securing the potentiometer cover to the unloader cylinder.
3. Unsolder leads to the potentiometer and remove.
4. Loosen the setscrew on the potentiometer side of the flexible coupling.
5. Remove the locknut to remove the potentiometer from the base plate. The potentiometer should slip out of the coupling. (For early versions, three retainer clips that secure the potentiometer to the base plate will need removed.)
6. Install the new potentiometer and reassemble.
7. Adjustment:

ROUGH ADJUSTMENT is made with the slide valve fully unloaded and the control power off. Remove connector P5. With a digital voltmeter, measure the resistance across the red and white wires, having removed them from the SBC. The resistance should be 1000 +/- 50 ohms. If adjustment is necessary, loosen the locknut and rotate the potentiometer clockwise or counterclockwise until the resistance reading is a close to a 1000 ohms as possible. Retighten the locknut and replace wires.

NOTICE

MECHANICAL TRAVEL OF THE SLIDE VALVE POTENTIOMETER IS 300 DEGREES ROTATION WHEN THE SLIDE STOP IS CONFIRMED TO BE IN THE 2.2 VI POSITION. THE TRAVEL WILL BE LESS THAN 300 DEGREES IF THE SLIDE STOP IS IN ANY POSITION ABOVE 2.2 VI.

FINE ADJUSTMENT must be made with the slide valve fully unloaded and the compressor running. The Operating display at this time should indicate a slide valve position of 0%. If the display is greater than 0%, adjust potentiometer POT #4 on the SBC until 0% is indicated. If 0% is not attainable, get as close as possible and then proceed to the next step. The adjustments of POT #4 and POT #3 are interactive and POT #3 may require adjustment to allow POT #4 to come into range.

Completely load the slide valve. The display at this time should indicate 100%. If the display is less than 100%, adjust potentiometer POT #3 on the SBC until 100% is indicated.

Repeat this sequence until the slide valve indicates 0% fully unloaded and 100% fully loaded.

VOLUMIZER POTENTIOMETER REPLACEMENT AND ADJUSTMENT

The VOLUMIZER potentiometer is located under a cover on the right side of the compressor (facing shaft) at the inlet end. See Figure 5.

1. Shut off control power.
2. Remove the potentiometer cover and gasket.
3. Remove the potentiometer and mounting bracket.
4. Install new potentiometer and bracket.




Figure 6. Potentiometer

5. **ADJUSTMENT** must be made with the compressor running and the slide valve fully unloaded. With the slide stop at maximum (V_i) position, check that the potentiometer pushrod is in contact with the slide stop pushrod. If not, the bracket must be ground or trimmed until contact is made. Completely decrease the slide stop. The Operating display at this time should indicate a (V_i) of 2.2. If greater than 2.2, adjust potentiometer POT #2 on the SBC until 2.2 is indicated. If 2.2 is not obtainable, get as close as possible and proceed to the next step. Adjustment of POT #2 and POT #1 are interactive and POT #1 may require adjustment to allow POT #2 to come into range. Now, completely increase the slide stop. The display at this time should indicate a (V_i) of 5.0 (4.2 for TDSH 283SX, 4.5 for TDSB 355U). If less than 5.0 (4.2 for TDSH 283SX, 4.5 for TDSB 355U), adjust potentiometer POT #1 on the SBC until 5.0 (4.2 for TDSH 283SX, 4.5 for TDSB 355U) is indicated. Repeat this sequence until the slide stop indicates 2.2 when fully decreased and 5.0 (4.2 for TDSH 283SX, 4.5 for TDSB 355U) when fully increased.

NOTICE

THE TOTAL TRAVEL ON THE VOLUMIZER® POTENTIOMETER IS .394 INCH.

COMPRESSOR HYDRAULIC SYSTEM (The solenoid valves and manifold block are available as a sales order option)

The compressor hydraulic system moves the movable slide valve (MSV) to load and unload the compressor. It also moves the movable slide stop (MSS) to increase or decrease the compressor's volume ratio (V_i).

The hydraulic cylinder located at the inlet end of the TDS compressor serves a dual purpose. It is separated by a fixed bulkhead into two sections. The movable slide valve (MSV) section is to the left of the bulkhead and the movable slide stop (MSS) to the right. Both sections are considered double acting hydraulic cylinders as oil pressure moves the pistons in either direction.

Both sections are controlled by double-acting, four-way solenoid valves which are actuated when a signal from the appropriate microprocessor output energizes the solenoid valve.

Compressor Loading: The compressor loads when MSV solenoid YY2 is energized and oil flows from the oil manifold through valve ports P and B to cylinder port SC-2 and enters the load side of the cylinder. Simultaneously, oil contained in the unload side of the cylinder flows out cylinder port SC-1 through valve ports A and T to compressor closed thread port.

Compressor Unloading: The compressor unloads when MSV solenoid YY1 is energized and oil flows from the oil manifold through valve ports P and A to cylinder port SC-1 and enters the unload side of the cylinder. Simultaneously, oil contained in the load side of the cylinder flows out compressor port SC-2 through valve ports B and T to compressor closed thread port.

NOTICE

High Stage Operation: An alternative piping arrangement has been provided to increase slide valve response time during high stage operation.

CAUTION

NEVER OPEN VALVE 1 AND VALVE 2 AT THE SAME TIME DURING COMPRESSOR OPERATION.

Higher operating pressures will slow the compressor unloading response time. Unloading response time can be increased by closing valve 1 (oil manifold pressure) and opening valve 2 to compressor suction pressure. See Figure 7.


VOLUMIZER VOLUME RATIO CONTROL

VI Increase

The volume ratio V_i is increased when MSS solenoid YY3 is energized and oil flows from the oil manifold through valve ports P and A to cylinder port SC-3 and enters the increase side of the cylinder. Simultaneously, oil contained in the decrease side of the cylinder flows out cylinder port SC-4 through valve ports B and T to compressor closed thread port.

VI Decrease

The volume ratio V_i is decreased when MSS solenoid YY4 is energized and oil flows from the oil manifold through valve ports P and B to cylinder port SC-4 and enters the decrease side of the cylinder. Simultaneously, oil contained in the increase side of the cylinder flows out cylinder port SC-3 through valve ports A and T to compressor closed thread port.



MSV and MSS HYDRAULIC CYLINDER and SOLENOID VALVES

Figure 8. Hydraulic Schematic

LOW AMBIENT OPERATION

It is recommended that package oil separators be insulated as a minimum requirement to preserve the heat generated by the oil heaters, to prevent condensation and secure lubrication at start-up.

BALANCE PISTON PRESSURE REGULATOR FOR TDSH 355 COMPRESSORS

A Balance Piston Pressure Regulator is required to reduce the extended overbalance from the thrust balance piston at part load.




Figure 7. Pressure Regulating Valve

HIGH-STAGE SB-2 OIL SUPPLY LINE DIAGRAM: Shows the three additions described below arranged in parallel.

PRESSURE-REGULATING VALVE: Discharge pressure determines compressor thrust balance. The proper setting for the pressure-regulating valve is 50 psi below DISCHARGE pressure. This pressure may vary based on operating conditions.

SOLENOID VALVE: Energizing, or opening, the solenoid valve pressurizes the balance piston with full oil pressure from the oil manifold, bypassing the A4ALE Pressure Regulating Valve. De-energizing, or closing, the solenoid valve pressurizes the balance piston with oil pressure regulated by the A4ALE Pressure Regulating Valve.

Signals from the control panel operate the solenoid valve (output module 12 on Frick micro panel). The solenoid valve should open when the slide valve position is 70% or greater, and close when the slide valve position is 65% or less. These may vary based on operating conditions.

ORIFICE: The orifice ensures oil supply to the inlet end bearings during upset conditions such as start-up.

OPERATION

OPERATION AND START-UP INSTRUCTIONS

The Frick TDS_ Rotary Screw Compressor will be a component in an integrated system. As such the compressor requires some specific operation and conditions to ensure trouble-free running.

The information in this section of the manual provides the logical step-by-step instructions to properly start up and operate the TDS_ Rotary Screw Compressor in your Unit. Only matters which may influence the proper operation of the TDS_ compressor are included.

NOTICE

THE FOLLOWING SUBSECTIONS MUST BE READ AND UNDERSTOOD BEFORE ATTEMPTING TO START OR OPERATE THE UNIT.

INITIAL START-UP

Prior to the start-up, the prestart check must be accomplished. See Forms section for Checklist.

INITIAL START-UP PROCEDURE

Having performed the prestart check, the compressor unit is ready for start-up. It is important that an adequate gas load be available to load test the unit at normal operating conditions. The following points should be kept in mind during initial start-up.

1. For proper and safe operation, the compressor must be run at the proper speed and discharge pressure. Exceeding design conditions creates a potential hazard.
2. After 1 to 3 hours of operation adjust oil cooling system.
3. Pull and clean suction strainer after 24 hours of operation. If it is excessively dirty, repeat every 24 hours until system is clean. Otherwise, follow the normal maintenance schedule.
4. Perform baseline vibration analysis if equipment is available.

NORMAL START-UP PROCEDURE

1. Confirm system conditions permit starting the compressor.
2. Start.
3. Observe the compressor unit for mechanical tightness of the external piping, bolts and valves. Ensure that the machine has no oil and vapor leaks. If any of these occur, shut down the compressor and correct the problem as necessary using good safety precautions.

MAINTENANCE

GENERAL INFORMATION

This section provides instructions for normal maintenance, a recommended maintenance program, and troubleshooting and correction guides.

⚠ WARNING

THIS SECTION MUST BE READ AND UNDERSTOOD BEFORE ATTEMPTING TO PERFORM ANY MAINTENANCE OR SERVICE TO THE UNIT.

⚠ CAUTION

Cylinder assembly under high spring load. Consult manual before disassembly. Improper disassembly may cause injury due to spring tension release.

NORMAL MAINTENANCE OPERATIONS

When performing maintenance you must take several precautions to ensure your safety:

⚠ WARNING

1. IF UNIT IS RUNNING, PRESS [STOP] KEY.
2. DISCONNECT POWER FROM UNIT BEFORE PERFORMING ANY MAINTENANCE.
3. WEAR PROPER SAFETY EQUIPMENT WHEN COMPRESSOR UNIT IS OPENED TO ATMOSPHERE.
4. ENSURE ADEQUATE VENTILATION.
5. TAKE NECESSARY SAFETY PRECAUTIONS REQUIRED FOR THE REFRIGERANT BEING USED.

GENERAL MAINTENANCE

Proper maintenance is important in order to assure long and trouble-free service from your screw compressor. Some areas critical to good compressor operation are:

1. **Keep oil clean and dry, avoid moisture contamination.** After servicing any portion of the refrigeration system, evacuate to remove moisture before returning to service. Water vapor condensing in the compressor while running or more likely while shut down, can cause rusting of critical components and reduce life.
2. **Keep suction strainer clean.** Check periodically, particularly on new systems where welding slag or pipe scale could find its way to the compressor suction. Excessive dirt in the suction strainer could cause it to collapse, dumping particles into the compressor.
3. **Keep oil filters clean.** If filters show increasing pressure drop, indicating dirt or water, stop the compressor and change filters. Running a compressor for long periods with high filter pressure drop can starve the compressor of oil and lead to premature bearing failure. Dual oil filters are recommended so that the filters can be changed without shutting down the package.
4. **Avoid slugging the compressor with liquids (oil).** While screw compressors are probably the most tolerant of any compressor type available today about ingestion of some

liquid, they are not liquid pumps. Make certain a properly sized suction accumulator is used to avoid dumping liquid into compressor suction.

5. **Protect the compressor during long periods of shutdown.** If the compressor will be sitting for long periods without running, it is advisable to evacuate to low pressure and charge with oil (or dry nitrogen for packages). This is particularly true on systems known to contain water vapor.

6. **Preventive maintenance inspection** is recommended any time a compressor exhibits a noticeable change in vibration level, noise, or performance.

CHANGING OIL

⚠ WARNING

DO NOT MIX OILS of different brands, manufacturers, or types. Mixing of oils may cause excessive oil foaming, nuisance oil level cutouts, oil pressure loss, gas or oil leakage and catastrophic compressor failure.

Shut down the unit when changing oil. At the same time all oil filter cartridges must be changed and all oil strainer elements removed and cleaned. The procedure is as follows:

1. Stop the compressor unit.
2. Lock out the motor starter.
3. Close the suction and discharge service valves
4. Using appropriate equipment, lower the compressor pressure to 0 psig.
5. Open the drain valve(s) and drain oil into a suitable container.
6. Drain the oil filter(s) and the oil coolers.
7. Remove the old filter cartridges, and install new ones.
8. Remove, clean, and reinstall elements in the strainers.
9. Evacuate the unit.
10. Open the suction service valve and pressurize the unit to system suction pressure. Close the suction valve and leak test.
11. Add oil.
12. Open the suction and discharge service valves
13. Remove the lockout from the motor starter.
14. Start the unit

RECOMMENDED MAINTENANCE PROGRAM

In order to obtain maximum compressor performance and ensure reliable operation, a regular maintenance program should be followed. The compressor unit should be checked regularly for leaks, abnormal vibration, noise, and proper operation. A log should also be maintained. Oil analysis should be performed on a regular basis. It is a valuable tool that can identify the presence of moisture, acid, metallics and other contaminants that will shorten compressor life if not corrected. In addition, an analysis of the compressor vibration should be made periodically.

VIBRATION ANALYSIS

Periodic vibration analysis can be useful in detecting bearing wear and other mechanical failures. If vibration analysis is used as a part of your preventive maintenance program, take the following guidelines into consideration.

1. Always take vibration readings from exactly the same places and at exactly the same percentage of load.



- Use vibration readings taken from the new unit at start-up as the baseline reference.
- Evaluate vibration readings carefully as the instrument range and function used can vary. Findings can be easily misinterpreted.
- Vibration readings can be influenced by other equipment operating in the vicinity or connected to the same piping as the unit.

- Only use Frick oil or high quality oils approved by Johnson Controls-Frick for your application.
- Only use Frick filter elements. Substitutions must be approved in writing by Johnson Controls-Frick engineering or warranty claim may be denied.
- Participate in a regular, periodic oil analysis program to maintain oil and system integrity.

OIL QUALITY AND ANALYSIS

High quality and suitable oil is necessary to ensure compressor longevity and reliability. Oil quality will rapidly deteriorate in systems containing moisture and air or other contaminants. In order to ensure the quality of the oil in the compressor unit:

OPERATING LOG

The use of an operating log as included in this manual permits thorough analysis of the operation of a system by those responsible for its maintenance and servicing. Continual recording of gauge pressures, temperatures, and other pertinent information, enables the observer and serviceman to be constantly familiar with the operation of

MAINTENANCE SCHEDULE

This schedule should be followed to ensure trouble-free operation of the compressor unit.

MAINTENANCE	FREQUENCY OR HOURS OF OPERATION (MAXIMUM)																						
	200	1000	5000	8000	10,000	15,000	20,000	25,000	30,000	35,000	40,000	45,000	50,000	55,000	60,000	65,000	70,000	75,000	80,000	85,000	90,000	95,000	
Change Oil	As Directed By Oil Analysis																						
Oil Analysis	■	Every 6 Months																					
Replace Filters	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Clean Oil Strainers	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Clean Liquid Strainers	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Replace Coalescers								■					■									■	
Check and Clean Suction Strainer	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Check Alignment	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Check Coupling (a)	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Suction & Disch Flange Bolts (b)	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■	■
Vibration Analysis (c)	■	Every 6 Months, More Frequently If Levels Increase																					
Replace Shaft Seal	When Leak Rate Exceeds 7 - 8 Drops Per Minute																						

- Check bolts, shim packs, center inserts, keys, and all bolt torques.
- Verify tightness of bolts on suction and discharge flanges. See table below for torque requirements.
- Vibration measurement must be carried out continuously to obtain optimum preventative control on bearings. If not continuously controlled, then every 6 months, more frequently if levels increase.

NOTE: The bolt torque requirements for the compressor flange to separator flange are based on:

- Gaskets: Garlock® Blue-Gard® 3300
- Bolts: class 8.8 or stronger hex head bolts, lightly oiled and clean

TDSH Flange Bolt Torque				
TDS_ Compressor Model	Discharge Flange to Separator Flange		Suction Flange	
	Bolt Size (in.)	Torque (ft-lb)	Bolt Size (in.)	Torque (ft-lb)
163S	M20 X 2.5	100	M16 X 2.0	120
163L	M20 X 2.5	100	M16 X 2.0	120
193S	M20 X 2.5	140	M20 X 2.5	180
193L	M20 X 2.5	140	M20 X 2.5	160
233S	M20 X 2.5	160	M20 X 2.5	160
233L	M20 X 2.5	160	M20 X 2.5	200
233XL	M20 X 2.5	160	M22 X 2.5	220
283S	M22 X 2.5	230	M22 X 2.5	220
283L	M22 X 2.5	230	M22 X 2.5	220
283SX	M22 X 2.5	230	M24 X 3.0	220
355_	M24 X 3.0	240	M30 X 3.5	350

Table 5. TDSH Flange Bolt Torque

the system and to recognize immediately any deviations from normal operating conditions. It is recommended that readings be taken at least daily.

TROUBLESHOOTING GUIDE

Successful problem solving requires an organized approach to define the problem, identify the cause, and make the proper correction. Sometimes it is possible that two relatively obvious problems combine to provide a set of symptoms that can mislead the troubleshooter. Be aware of this possibility and avoid solving the "wrong problem".

ABNORMAL OPERATION ANALYSIS AND CORRECTION

Four logical steps are required to analyze an operational problem effectively and make the necessary corrections:

1. Define the problem and its limits.
2. Identify all possible causes.
3. Test each cause until the source of the problem is found.
4. Make the necessary corrections.

The first step in effective problem solving is to define the limits of the problem. If, for example, the compressor periodically experiences high oil temperatures, do not rely on this observation alone to help identify the problem. On the basis of this information the apparent corrective measure would appear to be a readjustment of the liquid injection system. Lowering the equalizing pressure on the thermal expansion valve would increase the refrigerant feed and the oil temperature should drop.

If the high oil temperature was the result of high suction superheat, however, and not just a matter of improper liquid injection adjustment, increasing the liquid feed could lead to other problems. Under low load conditions the liquid injection system may have a tendency to overfeed. The high suction superheat condition, moreover, may only be temporary. When system conditions return to normal the units' liquid injection will overfeed and oil temperature will drop. In solving the wrong problem a new problem was created.

When an operating problem develops compare all operating information on the MAIN OPERATING SCREEN with normal operating conditions. If an Operating Log has been maintained the log can help determine what constitutes normal operation for the compressor unit in that particular system.

The following list of abnormal system conditions can cause abnormal operation of the TDS_ compressor:

1. Insufficient or excessive gas load.
2. Excessively high suction pressure.
3. Excessively high suction superheat.
4. Excessively high discharge pressure.
5. Inadequate refrigerant charge or low receiver oil level.
6. Excessively high or low temperature coolant to the oil cooler.
7. Liquid return from system (slugging).
8. Refrigerant underfeed or overfeed to evaporators.
9. Blocked tubes in water cooled oil cooler from high mineral content of water.
10. Insufficient evaporator or condenser sizing.
11. Incorrect gas/refrigerant line sizing.

12. Improper system piping.
13. Problems in electrical service to compressor unit.
14. Air and moisture present in the system.

Make a list of all deviations from normal plant operation and normal compressor unit operation. Delete any items which do not relate to the symptom and separately list those items that might relate to the symptom. Use the list as a guide to further investigate the problem.

The second step in problem solving is to decide which items on the list are possible causes and which items are additional symptoms. High discharge temperature and high oil temperature readings on a display may both be symptoms of a problem and not casually related. High suction superheat or a low receiver level, however, could cause both symptoms.

The third step is to identify the most likely cause and take action to correct the problem. If the symptoms are not relieved move to the next item on the list and repeat the procedure until you have identified the cause of the problem. Once the cause has been identified and confirmed make the necessary corrections.

BARE COMPRESSOR REPLACEMENT

The following procedure is required only when a bare compressor is replaced in the field.

1. Verify that the starter is locked out.
2. Remove gas/refrigerant
3. Remove all tubing, piping, and wiring that is connected to the compressor.
4. Disconnect the coupling from the driver shaft.
5. While supporting the compressor assembly with a crane, remove the bolts at the compressor feet.
6. Thoroughly clean the compressor feet and mounting pads of burrs and other foreign matter to ensure firm seating of the compressor.
7. Thoroughly clean the new compressor and remove all cover plates and protection etc.
8. Install new gaskets and sealing in all connections.
9. Set the new compressor in place and shim feet where required.
10. Reattach the drive coupling.
11. Check the shaft alignment.
12. Complete tubing, piping, and wiring.

SHUTDOWN DUE TO IMPROPER OIL PRESSURE (High Stage and Booster)

The compressor must not operate with incorrect oil pressure.

1. Refer to CONTROL SETUP

TROUBLESHOOTING THE TDS_ COMPRESSOR (Frick RWB II Package)

SYMPTOM	PROBABLE CAUSES and CORRECTIONS
EXCESSIVE NOISE and VIBRATION	<p>Main oil injection valve may be closed. Open valve.</p> <p>Bearing damage or excessive wear. CONTACT Frick Factor or Frick.</p> <p>Coupling loose on shaft. Tighten coupling. Replace if damaged.</p> <p>Misalignment between driver and compressor. Realign driver and compressor.</p> <p>Refrigerant flood back. Correct system problem.</p>
SLIDE VALVE and/or SLIDE STOP WILL NOT MOVE	<p>4-way hydraulic control valve failed - repair or replace.</p> <p>Slide stop indicator rod stuck. Contact Frick Factor or Frick for assistance.</p> <p>Check both S.V. and S.S. potentiometer for wiring and resistance.</p> <p>Compressor must be running with sufficient oil pressure.</p> <p>Unloader piston stuck. Contact Frick Factor or Frick for assistance.</p> <p>Slipper seals worn out or damaged. Contact Frick Factor or Frick for assistance.</p>

NOTICE

Troubleshooting the compressor is limited to identifying the probable cause. If a mechanical problem is suspected contact the Service Department, Frick. DO NOT ATTEMPT TO DISASSEMBLE THE COMPRESSOR.

TROUBLESHOOTING THE HYDRAULIC SYSTEM

SYMPTOM	PROBABLE CAUSES and CORRECTIONS
SLIDE VALVE WILL NOT LOAD OR UNLOAD	<p>Solenoid coils may be burned out, replace.</p> <p>Valve may be closed. Open hydraulic service valves.</p> <p>Solenoid spool may be stuck or centering spring broken, replace.</p> <p>Check outputs 2 and 3 and fuses.</p> <p>Solenoid may be mechanically actuated by inserting a piece of 3/16" rod against armature pin and pushing spool to opposite end. Push A side to confirm unload capability. If valve works, problem is electrical.</p>
SLIDE VALVE WILL LOAD BUT WILL NOT UNLOAD	<p>A side solenoid coil may be burned out, replace.</p> <p>Dirt inside solenoid valve preventing valve from operating both ways, clean.</p> <p>Solenoid may be mechanically actuated by inserting a piece of 3/16" rod against armature pin and pushing spool to opposite end. Push A side to confirm unload capability. If valve works, problem is electrical.</p>
SLIDE VALVE WILL UNLOAD BUT WILL NOT LOAD	<p>A side solenoid coil may be burned out, replace.</p> <p>Dirt inside solenoid valve preventing valve from operating both ways, clean.</p> <p>Solenoid may be mechanically actuated by inserting a piece of 3/16" rod against armature pin and pushing spool to opposite end. If valve works, problem is electrical.</p>
SLIDE STOP WILL NOT FUNCTION EITHER DIRECTION	<p>Solenoid coils may be burned out, replace.</p> <p>Solenoid service valves may be closed, open.</p> <p>Manually actuate solenoid. If slide stop will not move mechanical problems are indicated. Consult Frick factor or Frick.</p>

TROUBLESHOOTING THE OIL PUMP AND SYSTEM

SYMPTOM	PROBABLE CAUSES and CORRECTIONS
PUMP WILL NOT PRODUCE ENOUGH OIL PRESSURE AT START-UP	Check that service valves are open. Filter cartridges may be blocked. Check PSID across filters. Strainer may be blocked. Clean. Oil pressure regulator set too low or stuck open. Readjust or repair. Pump worn out. Repair or replace.
OIL PRESSURE RAPIDLY DROPS OFF WHEN COMPRESSOR STARTS	Main oil injection throttling valve too wide open or oil pressure regulating valve improperly adjusted. Readjust both valves.
NOISE and VIBRATION	Pump strainer blocked. Clean. Pump worn out. Repair or replace.
OIL PRESSURE DROPS AS HEAD PRESSURE INCREASES	Normal behavior. Set main oil injection and oil pressure for maximum head pressure condition.
MAIN UNIT FILTER PSID IS TOO HIGH	Filters clogged with dirt. Replace. Oil is too cold. Allow oil to warm up and check again. Service valve on filter outlet is partially closed. Open valves fully.



READ THIS FIRST: COMPRESSOR PRESTART CHECKLIST

The following items **MUST** be checked and completed by the installer prior to the arrival of the Frick Field Service Supervisor. Details on the checklist can be found in this manual. Certain items on this checklist will be reverified by the Frick Field Service Supervisor prior to the actual start-up.

Mechanical Checks

- Package installed according to Frick publication 070.210-IB, Screw Compressor Foundations.
- Confirm that motor disconnect is open
- Isolate suction pressure transducer
- Pressure test and leak check unit
- Evacuate unit
- Check alignment
- Remove compressor drive coupling guard
- Remove coupling center and **DO NOT reinstall** (motor rotation must be checked without center)
- Check for correct position of all hand, stop, and check valves **PRIOR** to charging unit with **OIL** or **REFRIGERANT**
- Charge unit with correct type and quantity of oil
- Lubricate electric drive motor bearings **PRIOR** to checking motor rotation
- Check oil pump alignment (if applicable)
- Check for correct economizer piping (if applicable)
- Check separate source of liquid refrigerant supply (if applicable, liquid injection oil cooling)
- Check water supply for water-cooled oil cooler (if applicable, water cooled oil cooling)
- Check thermosyphon receiver refrigerant level (if applicable, thermosyphon oil cooling)
- Check for **PROPER PIPE SUPPORTS** and correct foundation
- Check to ensure **ALL** piping **INCLUDING RELIEF VALVES** is completed

Electrical Checks

- Package installed according to Frick publication 090.400-SB, Proper Installation of Electrical Equipment In An Industrial Environment.
- Confirm that main disconnect to motor starter and micro is open
- Confirm that electrical contractor has seen this sheet, **ALL PERTINENT WIRING** information, and drawings
- Confirm proper power supply to the starter package
- Confirm proper motor protection (breaker sizing)
- Confirm that all wiring used is stranded copper and is 14 AWG or larger (sized properly)
- Confirm all 120 volt control wiring is run in a separate conduit from all high voltage wiring
- Confirm all 120 volt control wiring is run in a separate conduit from oil pump and compressor motor wiring
- Confirm no high voltage wiring enters the micro panel at any point
- Check current transformer for correct sizing and installation
- Check all point-to-point wiring between the micro and motor starter
- Confirm all interconnections between micro, motor starter, and the system are made and are correct
- Ensure all electrical panels are free from installation debris, **METAL PARTICLES**, and moisture

After the above items have been checked and verified:

- Close the main disconnect from the main power supply to the motor starter
- Close the motor starter disconnect to energize the micro
- Manually energize oil pump and check oil pump motor rotation
- Leave micro energized to ensure oil heaters are on and oil temperature is correct for start-up
- DO NOT energize compressor drive motor!** This should only be done by authorized Factory Field Service Technicians.

Summary: The Frick Field Service Supervisor should arrive to find the above items completed. He should find an uncoupled compressor drive unit (to verify motor rotation and alignment) and energized oil heaters with the oil at the proper standby temperatures. Full compliance with the above items will contribute to a quick, efficient and smooth start-up.

The Start-up Supervisor will:

1. Verify position of all valves
2. Verify all wiring connections
3. Verify compressor motor rotation
4. Verify oil pump motor rotation
5. Verify the % of FLA on the micro display
6. Verify and finalize alignment (if applicable)
7. Calibrate slide valve and slide stop
8. Calibrate temperature and pressure readings
9. Correct any problem in the package
10. Instruct operation personnel

NOTE: Customer connections are to be made per the electrical diagram for the motor starter listed under the installation section and per the wiring diagram listed under the maintenance section of the IOM.

Please complete and sign this form & fax to 717-762-8624 as confirmation of completion.

Frick Sales Order Number: _____
 Compressor Model Number: _____
 Unit Serial Number: _____
 End User Name: _____
 Address of Facility: _____
 City, State, Zip: _____

Print Name: _____
 Company: _____
 Job Site Contact: _____
 Contact Phone Number: _____
 Signed: _____


DRIVE TRAIN ALIGNMENT

Ambient Temperature at Time of Alignment _____ Oil Separator Temperature at Time of Alignment _____
 Motor Coupling Type _____ Size _____ Distance Between Coupling Hub Faces _____
 Soft Foot Check OK as Found Shimming Required Amount of Shims used to Correct _____
 Indicator Readings in in./1000 mm Indicator Clamped to Motor Compressor
 Indicator Readings Facing Compressor Motor Magnetic Center Checked Marked N/A
 Compressor Coupling Hub Runout _____ Motor Coupling Hub Runout _____

Initial Cold Alignment

Initial Hot Alignment

Final Hot Alignment



Compressor Operating Log Sheet				Starter Operating Log Sheet			
Date				Average Current			
Time				Current Phase A			
Hour Meter Reading				Current Phase B			
Equip. Room Temp.				Current Phase C			
Suction Pressure				Full Load Amps			
Suction Temperature				Output Frequency			
Suction Superheat				Output Voltage			
Discharge Pressure				DC Bus Voltage			
Discharge Temperature				Input Power kW			
Corresponding Temperature				Actual Speed			
Oil Pressure				Speed Command			
Oil Temperature				Ambient Temp F.			
Oil Filter Pressure Drop				Convert Heatsink Temp. F.			
Separator Temperature				Baseplate Temp. F.			
Slide Valve Position				VSD Operating Mode			
Volume Ratio (VI)				Harmonic Filter Present			
Motor Amps / FLA %				Harmonic Filter Mode			
Capacity Control Setpoint				Water Pump Energized			
Oil Level				Precharge Relay Energized			
Oil Added				Trigger SCR's Energized			
Seal Leakage (Drops/Min.)				DC Inverter Link Current			
Evaporator. EWT F.				Motor Winding Temp. F.			
Evaporator LWT F.				Humidistat % RH			
Condenser EWT F.				Vyper Coolant Temp. F.			
Condenser LWT F.				Total kWh			


VIBRATION DATA SHEET

Date: _____
End User: _____
Address: _____


Sales Order Number: _____
Installing Contractor: _____
Service Technician: _____

Equipment ID (As in Microlog): _____
Compressor Model Number: _____
Compressor Serial Number: _____
Unit Serial Number: _____
National Board Number: _____
Running Hours: _____
Manufacturer and Size of Coupling: _____
Motor Manufacturer: RAM _____
Motor Serial Number: _____
RPM: _____ Frame Size: _____ H.P. _____
Refrigerant: _____
Ambient Room Temperature: _____ °F
Operating Conditions: _____


Final Hot Alignment



Total Thickness of Shims Added



SUCTION		DISCHARGE		OIL		SEPARATOR		SLIDE VALVE POSITION	%
Press	#	Press	#	Press	#	Temp	°F	Vi Ratio	
Temp	°F	Temp	°F	Temp	°F			F.L.A.	%



Index

A

accumulator, 3
Allowable Flange Loads, 12
Antifriction bearings, 6
ASHRAE, 3

B

balance piston, 5
Balance Piston Pressure Regulator, 17
bare compressor, 21

C

Capacity control, 6
Compressor Oil, 13
Compressor Operating Log Sheet, 25
Compressor Port Locations, 8
Compressor Prestart Checklist, 24
compressor shaft seal, 6
condensation, 3, 14
COOLWARE™, 3
corrosion, 5, 12
coupling, 21
Customer Connections, 13

D

dimensions, 7
discharge pressure, 6
discharge temperature, 3
drive coupling, 21
dry nitrogen, 12

E

Evacuation lines, 5

F

female rotor, 6
Foundation, 12

G

gaskets, 21

H

Holding Charge, 12
hydrocarbon gasses, 3

I

identification data plate, 3
Installation, 7
insulated, 16

L

lifting rings, 12
load surges, 3
Long term storage, 4
lubrication system, 5

M

maintenance, 19
male rotor, 6
male rotor shaft, 5
motor, 21

O

Oil analysis, 19
oil cooling system, 18
oil filter cartridges, 19
oil filters, 19
Oil Filter(S), 14
Oil Heater(S), 14
oil pressure, 5, 13
Oil Pump, 13
Oil quality, 20
oil seal, 5
oil strainer elements, 19
oil supply, 5
operating log, 20
orifice, 17
over-compression, 6

P

pipe hangers, 12
piping layouts, 3
piping stress, 12
potentiometer, 15
pressure ratio, 6
Prestart Checklist, 24

R

Rigging And Handling, 12
rotor housing, 6

S

serial number, 3
shaft alignment, 21
shipping gauges, 12
shutdown, 19
slide stop, 6
slide valve, 6
Starter Operating Log Sheet, 25
start-up, 16
Start-up, 24
storage, 12
suction accumulator, 19
suction line, 3
suction strainer, 18, 19

T

thermal stability, 6
traps, 3
troubleshooting, 19
Troubleshooting
Filter cartridges, 23
Oil Pressure, 23
Oil pressure regulator, 23
pressure regulating valve, 23
Pump, 23
Pump strainer, 23
service valves, 23
Strainer, 23

U

under-compression, 6
unloading, 6

V

vacuum, 5
Vacuum, 14
vacuum pump, 14
Vapor Pump, 3
vibration analysis, 18, 19
vibration level, 19
Volume Ratio, 16

W

Warranty, 4
water vapor, 19
Water vapor, 19

April 2016 Form Revisions

- p.2 – Added bookmark Table of Contents PDF functionality
- p.8 – Noted drawings reference 163 and 193
- p.16 – Removed typical package reference information
 - Update Vi adjustment by compressor model

- New Frick logo added throughout